



Add-on Corner Beds Components

Size	P15	P30	P45	P60	P75	B60	B80	B106	RBCP
60 X 60 X 90 X 15						2	1		2 X 15
60 X 60 X 90 X 30						4	2		2 X 30
60 X 60 X 90 X 45						6	3		2 X 45
60 X 60 X 90 X 60						8	4		2 X 60
60 X 60 X 90 X 75						10	5		2 X 75
90 X 90 X 120 X 15							2	1	2 X 15
90 x 90 x 120 x 30							4	2	2 X 30
90 x 90 x 120 x 45							6	3	2 X 45
90 x 90 x 120 x 60							8	4	2 X 60
90 x 90 x 120 x 75							10	5	2 X 75
120 x 120 x 160 x 15						1	1	2	2 X 15
120 x 120 x 160 x 30						2	2	4	2 X 30
120 x 120 x 160 x 45						3	3	6	2 X 45
120 x 120 x 160 x 60						4	4	8	2 X 60
120 x 120 x 160 x 75						5	5	10	2 X 75

P15 - Square Post 15cm. B60 - Board 60cm long. RBCP 15 - Large Corner post 15cm high and so on.
 RBCP - These Corner Posts are the large, double chunky posts.

Check the size you have purchased. Check that you have the correct components. It is a good plan to make a rough plan of the footprint on the ground to check that you see it the way round that you want it. Construction will be simpler if you have a clear picture from which to work.

1. Ascertain the side which will be common to both the Raised Bed and the Add-on Corner Raised Bed.
2. Remove one corner post from the common side of the Raised Bed, **A**. This should be the side which will remain short. Replace that corner post with a RBCP (Raised Bed Corner Post). Check that you have this post the correct way up if it looks wrong.
3. Add a short board to the remaining post on the Raised Bed to form a right angle, **B**. To the end of this board add the second Raised Bed Corner post **C**.
4. Fill the long side with the longer board.
5. Build up to the height required.

NOTE For the larger Corner Bed 120 x 120 x 160 the long side (or Hypotenuse) is made up of two boards B60 and B80 joined by the square post that came from the original Raised Bed.