

## <u>Assembly</u>

# RAISED BEDS and RAISED BED MODULES

No nails, no screws, no holes to dig

#### Contents:

Posts = 4 for full bed -2 for add on modules. Height dependant on bed ordered. Boards = 4 per layer for full bed /3 per layer for add on module

For Long/Handy Beds there will be two sizes of board for opposite sides

## For the Beds

- 1. Slide a groove of a corner post over one end of a board
- 2. Take a second corner post and slide it over the other end of the board.
- 3. Repeat to form a square or rectangle
- 4. Build up the sides to the top of the posts

We recommend you place a flat stone or piece of slate under each post when in use. Or, you can use Post Slippers as found on our website <a href="https://www.gardeningworks.co.uk/Post-Slippers-Pair-Protective.html">https://www.gardeningworks.co.uk/Post-Slippers-Pair-Protective.html</a>

## For the Add on Modules

1. Repeat the above method of assembly using the two posts on one side of the four sided unit to support the Module.

Spare boards and posts are available via https://www.gardeningworks.co.uk/Raised-Wooden-Bed-Spares/

We have hand dipped in a non-toxic wood protection. To extend the life of your Raised Beds we recommend that you treat it every few years with a similar wood protective treatment. It is an opportunity to reverse the boards and posts to even out wear. You will find tins of the original Croma protective treatment for sale on the website <a href="https://www.gardeningworks.co.uk/Croma-Non-Toxic-Wood-Timber-Protective-Treatment.html">https://www.gardeningworks.co.uk/Croma-Non-Toxic-Wood-Timber-Protective-Treatment.html</a>